



## Preparing a STAYCOLD cabinet for transport

Your **STAYCOLD** cabinet requires collection and as a result we require it to be packed in a way that damages caused by transport are avoided and the unit is eventually returned to you in the best possible condition. Please follow the instructions below prior to the transporter arriving.

### Step 1

Remove all the shelves from the unit and pack them using either bubble wrap or cardboard so that they lie flat on the floor of the cabinet. Also remove any shelf hooks and pack in a bag.



### Step 2

Remove the Header Panel and bottom grill and wrap together. Place in the cabinet and ensure that the ends are protected from rubbing against the cabinet walls



### Step 3

On Hinge Door models, remove the door handles and also pack in plastic bag

### Step 4

On Sliding door models use a screw to secure the doors shut during transport



### Step 5

If possible protect the sides/corners with cardboard and wrap the unit in shrink wrap - when the transporter arrives ensure they use corner protectors when strapping/securing the unit

